






Set Scanfob 2005 Bluetooth scanner with special UPC-A settings

Scan all barcodes in the box of your desired settings.




No leading zero, transmit check digit

BEGIN	
No lead, send check	
END	



No leading zero, no transmit check digit

BEGIN	
No lead, no check	
END	

Transmit leading zero and check digit
(EAN-13)

BEGIN	
Leading, send check	
END	

Transmit leading zero, no check digit

BEGIN	
Leading, no check	
END	