

LaserChamp 2 Control Codes



LaserChamp 2 Control Codes



Disable Decode ITF (interleaved 2 of 5)*



Enable Decode ITF (interleaved 2 of 5)



Disable Decode Codabar*



Enable Decode Codabar



Disable Strip UPC Check Sum*



Enable Strip UPC Check Sum



Disable Verify ITF Check Sum*



Enable Verify ITF Check Sum



Disable Strip ITF Check Sum*



Enable Strip ITF Check Sum



Disable Verify Code39 Check Sum*




Enable Verify Code39 Check Sum




Disable Decode UPCA EAN13



Enable Decode UPCA EAN13*



Disable Decode UPCE



Enable Decode UPCE*



Disable Decode EAN8



Enable Decode EAN8*



Disable Decode Code 128



Enable Decode Code 128*



Disable Decode Code 39



Enable Decode Code 39*

LaserChamp 2 Control Codes



LaserChamp 2 Control Codes



Disable UPCE to UPCA Expand*



Enable UPCE to UPCA Expand



Disable UPCA to EAN13 Expand*



Enable UPCA to EAN13 Expand



Disable UPCA to EAN14 Expand*



Enable UPCA to EAN14 Expand