


Essential Mode Switching Barcodes

These control barcodes are valid **ONLY** to LaserChamp scanners running firmware version x.36.xx. These scanners would have been purchased after August 01, 2006.

Switch to Legacy Mode




Switch to Plus Mode



Switch to Basic Mode

(Compatibility, Ignore extensions)

Must first scan “Switch to Plus Mode” above



Note: Barcodes can only be read from opposite modes. Ex. Switch to Legacy barcode can only be scanned if scanner is in PLUS mode. And vice-versa...