HID Initial Delay

HID Initial Delay = Disabled	HID Initial Delay = 1second
H0000	H0001
HID Initial Delay = 2seconds	HID Initial Delay = 3seconds
H0002	H0003
HID Initial Delay = 5seconds	HID Initial Delay = 10seconds
H0005	HOOOA