







































System















※ Note 1. 4M Model Only

※ Note 2. 8M Model Only

<p>Memory Size = 0.5M / 3.5M ^{Note1,2}</p>  <p>5E000</p>	<p>Memory Size = 1M / 3M ^{Note1,2}</p>  <p>5E001</p>
<p>Memory Size = 2M / 2M ^{Note1,2}</p>  <p>5E002</p>	<p>Memory Size = 3M / 1M ^{Note1,2}</p>  <p>5E003</p>
<p>Memory Size = 4M / 0M ^{Note1,2}</p>  <p>5E004</p>	<p>Confirm Memory Size Change ^{Note1,2}</p>  <p>5E100</p>
<p>Memory Size = 5M / 3M ^{Note2}</p>  <p>5E005</p>	<p>Memory Size = 6M / 2M ^{Note2}</p>  <p>5E006</p>
<p>Memory Size = 7M / 1M ^{Note2}</p>  <p>5E007</p>	<p>Memory Size = 8M / 0M ^{Note2}</p>  <p>5E008</p>
<p>Memory Status</p>  <p>50001</p>	<p>Reset Memory</p>  <p>50002</p>

<p>Erase Memory</p>  <p>50003</p>	<p>Reset App data</p>  <p>50004</p>
<p>Reset BT Registry</p>  <p>50005</p>	
<p>Enable Auto Erase</p>  <p>5F001</p>	<p>Disable Auto Erase</p>  <p>5F010</p>
<p>Date/Time</p>  <p>52001</p>	<p>Battery</p>  <p>53001</p>
<p>Display Version</p>  <p>54001</p>	
<p>Lock Button</p>  <p>55001</p>	<p>Unlock Button</p>  <p>55010</p>
<p>Enable Beep Sound</p>  <p>56001</p>	<p>Disable Beep Sound</p>  <p>56010</p>

<p>High Beep Volume</p>  <p>5D001</p>	<p>Low Beep Volume</p>  <p>5D010</p>
<p>Enable Auto Menu Exit</p>  <p>58001</p>	<p>Disable Auto Menu Exit</p>  <p>58010</p>
<p>Enable MFi Mode</p>  <p>6M001</p>	<p>Disable MFi Mode</p>  <p>6M010</p>
<p>Enable Vibrator</p>  <p>5G001</p>	<p>Disable Vibrator</p>  <p>5G010</p>
<p>Scan Success = No vibration</p>  <p>5S000</p>	<p>Scan Success = 1 vibration</p>  <p>5S001</p>
<p>Scan Success = 2 vibrations</p>  <p>5S002</p>	<p>Scan Success = 3 vibrations</p>  <p>5S003</p>
<p>Scan Success = 4 vibrations</p>  <p>5S004</p>	<p>Scan Success = 5 vibrations</p>  <p>5S005</p>

<p>Scan Failure = No vibration</p>  <p>5S200</p>	<p>Scan Failure = 1 vibration</p>  <p>5S201</p>
<p>Scan Failure = 2 vibrations</p>  <p>5S202</p>	<p>Scan Failure = 3 vibrations</p>  <p>5S203</p>
<p>Scan Failure = 4 vibrations</p>  <p>5S204</p>	<p>Scan Failure = 5 vibrations</p>  <p>5S205</p>
<p>Enable Port Status</p>  <p>58101</p>	<p>Disable Port Status</p>  <p>58100</p>
<p>Display Format = Time & Battery</p>  <p>58200</p>	<p>Display Format = Type & Time</p>  <p>58201</p>
<p>Display Format = Type & Battery</p>  <p>58202</p>	<p>Display Format = Memory Status</p>  <p>58203</p>
<p>Display Format = GPS Data (GPS Model)</p>  <p>58204</p>	<p>Display Format = Barcode Only</p>  <p>58205</p>

<p>Display Format = Graphic</p>  <p>58206</p>	
<p>Enable Scrolling</p>  <p>59001</p>	<p>Disable Scrolling</p>  <p>59010</p>
<p>Factory Default</p>  <p>57001</p>	<p>KDC Reset</p>  <p>A0000</p>
<p>Enable Backup Battery (KDC20/20D Only)</p>  <p>5R001</p>	<p>Disable Backup Battery (KDC20/20D Only)</p>  <p>5R010</p>