





Enabling Only Specific Barcode Symbologies on the Scanfob® 2005

Scan the “BEGIN” barcode, then the desired setting, followed by the “END” barcode to complete the configuration.

Enable only specific codes



Enable all codes (excluding add-on codes)



Please contact SerialIO.com if more code options are needed.