

SCANFOB® 3002i


Feedback Options

Beeper Options

Enable / Disable Beeper on Startup



Enable



Disable

Enable / Disable Beeper on Barcode Read



Enable




Disable

Beeper Volume



High



Mid-High



Mid-Low




Low


Beeper Tone Pattern by Frequency (Hz)



High



Mid



Low



High to Low




Low to High

Beeper Duration in milliseconds



50ms



75ms



100ms



200ms



400ms


Feedback Options

Vibrate Options

Enable / Disable Vibrate on Startup



Enable



Disable

Enable / Disable Vibrate on Barcode Read




Enable




Disable

Vibrate Strength



String



Normal



Weak

Vibrate Duration in milliseconds



50ms



100ms



200ms



400ms

Scanfob® 3002i Support Page:

<http://serialio.com/support/scanfob%C2%AE-3002i-wireless-2d1d-barcode-scanner-support>

Scanfob® 3002i Product Page:

<https://serialio.com/products/barcode-scanners/bluetooth-wireless/scanfob%C2%AE-3002i>